

Renew-Crete® Systems

**Innovative Products
For An Innovative Industry**



Re-Coat



For the Ultimate in concrete repair & resurfacing, rely on Renew-Crete®.

Re-Coat is a co-polymer modified resurfacing compound especially formulated to dry to a light gray color to resemble newly cured concrete. *Re-Coat* is perfect to restore old stained concrete surfaces, rain damaged slabs, scaling or dusting concrete. This product can be applied from a featheredge up to ½” thick, broomed, squeegeed, or troweled on. *Re-Coat* is available in 30 standard colors as well as neutral gray. *Re-Coat* is a simpler, more cost effective choice than tearing out and replacing an existing slab. The material cost is about .16-.20 cents per sq. ft. with one coat for neutral gray and approximately .35-.40 cents per sq. ft. for colored and sealed *Re-Coat*.

Directions:

Surface Preparation:

The concrete surface must be clean and free of all loose material, oil residue, sealers or paints. Clean thoroughly by using a pressure washer with a degreaser or stripper if necessary. Etch the surface using a 1-4 muriatic acid solution. Rinse clean and neutralize.

Mixing instructions 45 Lb. Unit:

In a clean 5-gallon pail measure 1.25 gallons of clean water. Using a drill with a mixing wand, slowly add the dry *Re-Coat* to the water as you are running the mixing wand. Once you have added all the material, continue to mix thoroughly for 2 minutes to a fluid consistency with no lumps. You may add up to 1 additional pint of water if needed.

Application Instructions:

Patch & leveling: Start by misting the surface with water, (surface should be damp only, no standing water) then apply the *Re-Coat* mix. Screed where necessary, smooth with a round edged fresno or pool trowel, keeping all tools clean and moist., finish as desired (i.e. broom texture, etc.) Allow all patch and leveled areas to dry before applying *Re-Coat* (1-5 hours). It is also a good idea to smooth the edges around patches with a damp sponge within 2 hours.

Broom Finish: Start by misting the surface with water, then apply the *Re-Coat* with squeegee, allow material to dry slightly (3-10 Minutes), then follow with a broom.

Note: If a great deal of patching has been done you may need to apply second coat over the entire area to ensure color uniformity. Wait until the first application is dry, (1-3 hours) and then re-apply.

Coverage: 1-45 Lb. unit will cover approximately. 150-250 sq. ft. broomed or squeegeed, 22 sq. ft. at ¼” thick.



Re-Coat, another innovative product from Renew-Crete® Systems!